




## PROFICIENT STABILIZED IFR APPROACH

APPROACH CLEARANCE:

## SAMPLE APPROACH PROFILE

A Cessna 172\*

## **ACTION**



<sup>\*</sup>Example only. Reference your Aircraft's POH

Find resources and watch the entire video series at AirSafetyInstitute.org/beyondproficient/IFR