

LOC/DME I-OJW  
**108.3**  
Chan 20

APP CRS  
**183°**

Rwy Idg  
TDZE **54**  
Apt Elev **56**

LDA RWY 20R

JOHN WAYNE/ORANGE COUNTY (SNA)

DME required.  
Circling Rwy 20L NA at night. For inop ALS, increase S-LDA 20R Cat C/D visibility to RVR 6000.

MALSR  
AS

MISSED APPROACH: Climb to 1000 then climbing right turn to 3000 direct SLI VORTAC and hold.

|                        |                                     |                                                          |                         |                          |       |                         |
|------------------------|-------------------------------------|----------------------------------------------------------|-------------------------|--------------------------|-------|-------------------------|
| D-ATIS<br><b>126.0</b> | SOCAL APP CON<br><b>121.3 263.1</b> | JOHN WAYNE TOWER ★<br><b>126.8</b> (CTAF) <b>343.625</b> | GND CON<br><b>120.8</b> | CLNC DEL<br><b>118.0</b> | CPDLC | UNICOM<br><b>122.95</b> |
|------------------------|-------------------------------------|----------------------------------------------------------|-------------------------|--------------------------|-------|-------------------------|

