

VORTAC MMB
115.6
Chan **103**

APP CRS
062°

Rwy Idg
TDZE
Apt Elev
N/A
N/A
2189

VOR/DME-A
WEST WOODWARD (WWR)

⚠

When local altimeter setting not received, use Gage altimeter setting and increase all MDA 40 feet. Circling NA to Rwy's 5 and 23.

MISSED APPROACH: Climb to 4000, then left turn via MMB VORTAC R-062 to NARAH/MMB VORTAC 13 DME and hold.

AWOS-3 118.425	KANSAS CITY CENTER 126.95 379.2	UNICOM 122.8 (CTAF) 0
--------------------------	---	--

