

TETLIN (3T4) 1 S UTC-9(-8DT) N63°07.48' W142°31.11'
1671 B NOTAM FILE ORT
RWY 08-26: 3300X75 (GRVL) MIRL

RWY 08: Brush.

RWY 26: Brush.

SERVICE: LGT ACTIVATE MIRL Rwy 08-26 —CTAF.

AIRPORT REMARKS: Unattended. Rwy condition not monitored, recommend visual inspection prior to using. Skis not recommended.

AIRPORT MANAGER: 907-883-5128

COMMUNICATIONS: CTAF 122.9

RADIO AIDS TO NAVIGATION: NOTAM FILE ORT.

NORTHWAY (H) VORTAC 116.3 ORT Chan 110 N62°56.83'
W141°54.76' 286° 19.7 NM to fld. 1779/17E.


TACAN AZIMUTH unusable:

342°-037° byd 30 NM blo 10,500'

DME unusable:

342°-037° byd 30 NM blo 10,500'

COMM/NAV/WEATHER REMARKS: For a toll free call to Northway FSS dial 1-800-478-6611.



THOMPSON PASS (See VALDEZ on page 254)

THORNE BAY SPB (KTB) 0 NW UTC-9(-8DT) N55°41.28' W132°32.20'

KETCHIKAN

00 NOTAM FILE KTN

WATERWAY NW-SE: 5000X2000 (WATER)

AIRPORT REMARKS: Unattended. Opr area in Thorne Bay. Be alert: sea otters also use SPB ramp/tie-down area.

AIRPORT MANAGER: 907-204-0815

COMMUNICATIONS: CTAF 122.9

RADIO AIDS TO NAVIGATION: NOTAM FILE ANN.

ANNETTE ISLAND (H) (H) VOR/DME 117.1 ANN Chan 118

N55°03.62' W131°34.70' 298° 50.0 NM to fld. 184/21E.

VOR unusable:

000°-100° byd 11 NM blo 12,000'

000°-100° byd 15 NM

000°-100° byd 9 NM blo 6,500'

120°-130° byd 37 NM blo 6,000'

290°-320° byd 32 NM blo 7,000'

290°-320° byd 37 NM blo 9,000'

345°-000° byd 20 NM

DME unusable:

000°-100° byd 11 NM blo 12,000'

000°-100° byd 15 NM

000°-100° byd 9 NM blo 6,500'


120°-130° byd 37 NM blo 6,000'

290°-320° byd 32 NM blo 7,000'

290°-320° byd 37 NM blo 9,000'

345°-000° byd 20 NM

COMM/NAV/WEATHER REMARKS: For a toll free call to Ketchikan FSS dial 1-800-478-3500. For a LC to Juneau FSS dial 789-7380.



TIBBETTS (See NAKNEK on page 176)